



Our retail price is a recommendation only. Prices in offer may differ. All prices indicated 0,00 € will follow in the offer.



ROBERT BOSCH POWER TOOLS GMBH 10-PIECE JIGSAW BLADE SET BASIC FOR WOOD. FOR JIGSAWS

SKU: 3165140579353

10-piece jigsaw blade set Basic for Wood. For jigsaws

Categories: [Accessories for BOSCH professional](#), [Saws](#)

Product Features: Set contents: T 119 BO
Basic for Wood

Set contents: T 119 B Basic for Wood

Set contents: T 111 C Basic for Wood

Benefit HL (short): Cuts in Wood

Performance Claim Text: Cuts in Wood

(Version) Key RTB: Contains blades for

straight and curve cuts in soft wood

Material: Softwood

Material: Plywood

Material: Chipboard

Product text, Accessories grey: 10-piece
jigsaw blade set Basic for Wood

SOL Date: 01.02.2010

Novelty: no

Scope of delivery:

1 ST 10-piece jigsaw blade set Basic for
Wood. For jigsaws |

PRODUCT DESCRIPTION

The Basic for Wood Jigsaw Blade Set, Cassette, 10-Pieces delivers cuts in wood. It contains blades for straight and curve cuts in soft wood.

Article ID: 2607010629

PRODUCT DATASHEET LEGAL NOTE



Please note that the information on this datasheet is provided without warranty and is intended only as non-binding information about the product. Any liability for damages or losses that may arise from the use of this information is excluded. We therefore recommend that you verify the information on this datasheet with other sources before making any decisions based on this information. Additional information about the product can be found on our website.