



Our retail price is a recommendation only. Prices in offer may differ. All prices indicated 0,00 € will follow in the offer.



ROBERT BOSCH POWER TOOLS GMBH 10-PIECE T-SHANK JIGSAW BLADE SET FOR WOOD. FOR JIGSAWS

SKU: 3165140913409

10-piece T-Shank Jigsaw blade Set for Wood. For jigsaws

Categories: Accessories for BOSCH professional, Saws

Product Features: Set contents: T 119 BO

Basic for Wood

Set contents: T 119 B Basic for Wood
Set contents: T 111 C Basic for Wood
Set contents: T 244 D Speed for Wood
Set contents: T 144 D Speed for Wood
Set contents: T 144 D Speed for Wood
Set contents: T 101 AO Clean for Wood
Set contents: T 101 B Clean for Wood
Set contents: T 101 B Clean for Wood
Set contents: T 101 D Clean for Wood
Set contents: T 101 D Clean for Wood
Performance Claim Text: Cuts in Wood
Version Key PTP: Contains blades for rough

(Version) Key RTB: Contains blades for rough, fast and fine cuts as well as for straight and

curve cuts in softwood Material: Softwood Material: Plywood Material: Chipboard

Product text, Accessories grey: 10-piece

jigsaw blade set Wood SOL Date: 01.05.2017

Novelty: no

Scope of delivery: 5 ST 10-piece T-Shank Jigsaw blade Set for Wood. For jigsaws |





PRODUCT DESCRIPTION

The Wood Jigsaw Blade Set, 10-Pieces is the ideal choice for applications in wood. It contains blades for rough, fast and fine cuts as well as for straight and curve cuts in softwood.

Article ID: 2607011169

PRODUCT DATASHEET LEGAL NOTE

Please note that the information on this datasheet is provided without warranty and is intended only as non-binding information about the product. Any liability for damages or losses that may arise from the use of this information is excluded. We therefore recommend that you verify the information on this datasheet with other sources before making any decisions based on this information. Additional information about the product can be found on our website.