



Our retail price is a recommendation only. Prices in offer may differ. All prices indicated 0,00 € will follow in the offer.



ROBERT BOSCH POWER TOOLS GMBH CORDLESS JIGSAW EASYSAW 18V-70

SKU: 4053423229912

Cordless Jigsaw EasySaw 18V-70

Categories: [Battery-powered tools](#), [BOSCH](#)
[Power tools DIY and gardening](#), [Saws](#)

Product Features: Battery compatibility: 18V

POWER FOR ALL ALLIANCE

Battery recommendation: ≥ 1.5 Ah

No-load stroke rate, from: 0 spm

No-load stroke rate, up to: 2.600 spm

Stroke rate at no load: 0 - 2,600 spm

Sole plate: Steel

Cutting depth in wood: 70 mm

Cutting depth in steel: 6 mm

Cutting depth in aluminium: 15 mm

10.8 Volt: no

12 Volt: no

14.4 Volt: no

18 Volt: no

Lithium-ion technology: no

Bosch SDS: no

Bosch Low Vibration: no

Bosch Electronic: no

Pendulum action: no

Bosch CutControl: no

Integrated work light: no

Speed preselection: no

Aluminium base plate: no

Dust blowing function: no

Bosch SDS sole plate adjustment: no

Tool-Box: no

Softgrip: no

Bosch Electronic Cell Protection (ECP): no

Vibration emission value ah [Sawing wood]:
8,5 m/s²

Uncertainty K [Sawing wood]: 2,5 m/s²

Vibration emission value ah [Sawing sheet
metal]: 10,0 m/s²



Uncertainty K [Sawing sheet metal]: 2,0 m/s²
Battery voltage: 18 V
Battery capacity: 0,0 Ah
Tool dimensions (L x W x H): 235 x 80 x 195 mm
Weight: 1,3 kg
Packaging dimensions (length): 230 mm
Packaging dimensions (width): 300 mm
Packaging dimensions (height): 95 mm
Packaging dimensions (L x W x H): 230 x 300 x 95 mm
Product short description: Easy-to-use, lightweight jigsaw for tackling at-home jobs
TOP product characteristics: Easy sawing operation with just one button
TOP product characteristics: Perfect for cutting wood up to 70-mm depth, e.g., laminate flooring
TOP product characteristics: Effortless control with speed trigger for a soft start and speed change
TOP product characteristics: Straight and curved cutting versatility on wood, plastic, and metal
TOP product characteristics: Easy blade changes with SDS system
Product category subdivision: Cordless Jigsaw
Usage level: Easy
Title: Cordless Jigsaw EasySaw 18V-70
Scope of supply: 1 saw blade T 144 D (2 608 630 040)**
Scope of supply: ** Further purchase only in set of 5
Scope of supply: Carton
SOL Date: 15.09.2021
Novelty: no
Novelty until: 15.12.2021

Scope of delivery:
1 ST Cordless Jigsaw EasySaw 18V-70 |

PRODUCT DESCRIPTION

Cordless Jigsaw EasySaw 18V-70, Easy-to-use, lightweight jigsaw for tackling at-home jobs, Easy sawing operation with just one button, Perfect for cutting wood up to 70-mm depth, e.g., laminate flooring, Effortless control with speed trigger for a soft start and speed change, Straight and curved cutting



versatility on wood, plastic, and metal, Easy blade changes with SDS system, 1 saw blade T 144 D (2 608 630 040)**, ** Further purchase only in set of 5, Carton

Article ID: 0603012000

PRODUCT DATASHEET LEGAL NOTE

Please note that the information on this datasheet is provided without warranty and is intended only as non-binding information about the product. Any liability for damages or losses that may arise from the use of this information is excluded. We therefore recommend that you verify the information on this datasheet with other sources before making any decisions based on this information. Additional information about the product can be found on our website.