



Our retail price is a recommendation only. Prices in offer may differ. All prices indicated 0,00 € will follow in the offer.



ROTHENBERGER CORDLESS PIPE CLEANING MACHINE RODRUM VARIOCLEAN FOR PIPE DM 40-100 MM 18 V 8 AH

SKU: 4004625536759

1,00 ST Cordless pipe cleaning machine
RODRUM VarioClean for pipe dm 40-100 mm
18 V 8 Ah

Categories: [Cordless pipe cleaning machines](#), [Cordless tools](#)

Product Features: For pipe Ø: 40-100 mm
For pipe cleaning springs: Ø 10-13 mm spirals
Revolution speed: 275/340/395 U/min
Weight: 24.1 kg
Battery voltage: 18 V
Battery capacity: 8 Ah
Brand: ROTHENBERGER

Scope of delivery:

1,00 ST Cordless pipe cleaning machine
RODRUM VarioClean for pipe dm 40-100 mm
18 V 8 Ah |

PRODUCT DESCRIPTION

RODRUM VarioClean

- Rechargeable battery-based drum machine with automatic forward and return motion for cleaning pipes with Ø 40-100 mm
- 10 mm spiral drum for work areas of 40 to 70 mm pipe Ø, 13 mm spiral drum for work areas of 50 to 100 mm pipe Ø, CAS battery drive for wireless work and greater electrical safety
- Electronics: Three speed levels for blockage removal, cleaning and force cleaning
- Prevents the long overrun of the drum
- DuraFlex spirals: Extremely flexible galvanised spirals
- Interchangeable spiral drum for tool-free adjustment to other pipe Ø
- Removable spiral drum for easy transport
- Clean and discrete working principle compared to a portable case machine Further technical information:
- Subject to audit: Yes Scope of supply: RODRUM VarioClean basic equipment, incl. 15 m DuraFlex spirals



13 mm Guide hose Twist guide glove, rubber, pair RO BC14/36 charger, 230 V, EU RO BP18/8, 8.0 Ah 18 V Li-HD rechargeable battery Operating instructions Note on the disposal of batteries and rechargeable batteries As we sell batteries and rechargeable batteries and devices that contain batteries and rechargeable batteries, under the German Battery Act (BattG) we are obliged to draw your attention to the following: The symbol of the waste bin with the X through it on batteries and rechargeable batteries means that they must not be disposed of in household waste after consumption. If batteries or rechargeable batteries contain mercury, cadmium or lead, you will find the chemical symbol (Hg, Cd or Pb) under the symbol of the waste bin with the X through it. Every user of batteries or rechargeable batteries is legally obliged to return old batteries and rechargeable batteries. They can be returned, free of charge, to the retailer or another collection point near you. You can obtain the addresses of suitable collection points near you from your local government authority. In the case of batteries that contain more than 0.0005 percent by mass mercury, more than 0.002 percent by mass cadmium or more than 0.004 percent by mass lead, the chemical symbols of the respective harmful substance used are indicated under the waste bin symbol. The chemical symbols have the following meaning: Pb: Battery contains lead Cd: Battery contains cadmium Hg: Battery contains mercury

PRODUCT DATASHEET LEGAL NOTE

Please note that the information on this datasheet is provided without warranty and is intended only as non-binding information about the product. Any liability for damages or losses that may arise from the use of this information is excluded. We therefore recommend that you verify the information on this datasheet with other sources before making any decisions based on this information. Additional information about the product can be found on our website.