



Our retail price is a recommendation only. Prices in offer may differ. All prices indicated 0,00 € will follow in the offer.



ROTHENBERGER CORDLESS PIPE CLEANING MACHINE R600 VARIOCLEAN FOR PIPE DM 20-150 MM 18 V 8 AH

SKU: 4004625536612

1,00 ST Cordless pipe cleaning machine R600
VarioClean for pipe dm 20-150 mm 18 V 8 Ah

Categories: [Cordless pipe cleaning machines](#), [Cordless tools](#)

Product Features: For pipe Ø: 20-150 mm
Working length: 60 m with Ø 8-22 mm
For pipe cleaning springs: Ø 8-22 mm spirals
Revolution speed: 427/527/614 U/min
Weight: 16.7 kg
Battery voltage: 18 V
Battery capacity: 8 Ah

Scope of delivery:

1,00 ST Cordless pipe cleaning machine R600
VarioClean for pipe dm 20-150 mm 18 V 8 Ah

|

PRODUCT DESCRIPTION

Rechargeable battery-based pipe cleaning machine for effective removal of blockages in drains up to Ø 150 mm

- CAS rechargeable battery drive: For wireless operation and greater electrical safety
- Electronics: Three speed levels for blockage removal, cleaning and force cleaning
- Optimal adjustment options to the blockage type
- DuraFlex spirals: Extremely flexible galvanised spirals
- Optimised for use with rechargeable battery-operated R600 VarioClean
- Universally applicable for indoor and outdoor use
- Compact design and light weight Further technical information:
- Subject to audit: Yes Scope of supply: R600 VarioClean basic equipment Shoulder strap, incl. 16 mm/22 mm separating pin Guide hose RO BC14/36 charger, 230 V, EU RO BP18/8, 8.0 Ah 18 V Li-HD rechargeable battery ROCASE 4212, with insert for 2x rechargeable batteries, 1x charger Twist guide glove, rubber, pair Operating instructions Note on the disposal of batteries and rechargeable batteries As we sell batteries and rechargeable batteries and devices that contain batteries and rechargeable batteries, under the



German Battery Act (BattG) we are obliged to draw your attention to the following: The symbol of the waste bin with the X through it on batteries and rechargeable batteries means that they must not be disposed of in household waste after consumption. If batteries or rechargeable batteries contain mercury, cadmium or lead, you will find the chemical symbol (Hg, Cd or Pb) under the symbol of the waste bin with the X through it. Every user of batteries or rechargeable batteries is legally obliged to return old batteries and rechargeable batteries. They can be returned, free of charge, to the retailer or another collection point near you. You can obtain the addresses of suitable collection points near you from your local government authority. In the case of batteries that contain more than 0.0005 percent by mass mercury, more than 0.002 percent by mass cadmium or more than 0.004 percent by mass lead, the chemical symbols of the respective harmful substance used are indicated under the waste bin symbol. The chemical symbols have the following meaning: Pb: Battery contains lead Cd: Battery contains cadmium Hg: Battery contains mercury

PRODUCT DATASHEET LEGAL NOTE

Please note that the information on this datasheet is provided without warranty and is intended only as non-binding information about the product. Any liability for damages or losses that may arise from the use of this information is excluded. We therefore recommend that you verify the information on this datasheet with other sources before making any decisions based on this information. Additional information about the product can be found on our website.