



Our retail price is a recommendation only. Prices in offer may differ. All prices indicated 0,00 € will follow in the offer.

ROTHENBERGER CORDLESS TUBE BENDING MACHINE SET ROBEND® 4000 E 1/2 - 5/8 - 3/4 - 7/8 - 1 1/8 INCH

SKU: 4004625536780



1,00 ST Cordless tube bending machine set ROBEND® 4000 E 1/2 - 5/8 - 3/4 - 7/8 - 1 1/8 inch

Categories: [Cordless tools](#), [Cordless tube bending machines](#)

Product Features: For pipe Ø: 12-35 mm
Bending angle: 180 °
Battery voltage: 18 V
Battery capacity: 4 Ah
Brand: ROTHENBERGER

Scope of delivery:
1,00 ST Cordless tube bending machine set ROBEND® 4000 E 1/2 - 5/8 - 3/4 - 7/8 - 1 1/8 inch |

PRODUCT DESCRIPTION

Robust rechargeable battery tube bender for bending up to 180°

- Deformation- and fold-free bending thanks to the patented ROLUB technology for better sliding capacity of the bending shoe
- Toolless presetting of the bending angle
- Automatic switch-off when reaching the desired bending angle - ideal for series production of identical bends
- Bending radius: 42-112 mm
- CAS rechargeable battery (for up to 60 bends with 28 mm copper pipe) Areas of use: - Suitable for copper, stainless steel and C steel pipes as well as multi-layer composite pipes - For use in the plumbing and cooling/air-conditioning sector Further technical information:
- Weight: 29.45kg
- Type: 1/2 - 5/8 - 3/4 - 7/8 - 1 1/8
- Subject to audit: Yes Scope of supply: Basic equipment, EU tripod, slide shoe axle, ROCASE 6427 with insert for ROBEND® 4000 E, bending sets, ROCASE 4212 with insert for 2x rechargeable batteries, 1x charger RO BP18/4, Li-Power rechargeable battery RO BC14/36 charger, 230 V Note on the disposal of batteries and rechargeable batteries As we sell batteries and rechargeable batteries and devices that



contain batteries and rechargeable batteries, under the German Battery Act (BattG we are obliged to draw your attention to the following: The symbol of the waste bin with the X through it on batteries and rechargeable batteries means that they must not be disposed on in household waste after consumption. If batteries or rechargeable batteries contain mercury, cadmium or lead, you will find the chemical symbol (Hg, Cd or Pb) under the symbol of the waste bin with the X through it. Every user of batteries or rechargeable batteries is legally obliged to return old batteries and rechargeable batteries. They can be returned, free of charge, to the retailer or another collection point near you. You can obtain the addresses of suitable collection points near you from your local government authority. In the case of batteries that contain more than 0.0005 percent by mass mercury, more than 0.002 percent by mass cadmium or more than 0.004 percent by mass lead, the chemical symbols of the respective harmful substance used are indicated under the waste bin symbol. The chemical symbols have the following meaning: Pb: Battery contains lead Cd: Battery contains cadmium Hg: Battery contains mercury

PRODUCT DATASHEET LEGAL NOTE

Please note that the information on this datasheet is provided without warranty and is intended only as non-binding information about the product. Any liability for damages or losses that may arise from the use of this information is excluded. We therefore recommend that you verify the information on this datasheet with other sources before making any decisions based on this information. Additional information about the product can be found on our website.